

DRC033 Descaling Instructions

Ice Making System

- 1 Turn knob to the off position
- 2 Remove all ice from the bin
- 3 Pour 4 oz. Scotsman "Clear 1" Scale Remover into the reservoir
- 4 Turn machine on and let run for 2 hours
- 5 Pour hot water into the bin to melt any ice that has formed. Ice will likely look frosty and white
- 6 Clean bin by mixing some cleaner with hot water and scrub remaining scale remover
- 7 Rinse bin with hot water
- 8 Turn knob clockwise to restart

Regular descaling and sanitizing of the bin and drain system is required



Part #19-0653 Clear One Concentrated Scale Remover



Scan QR Code for Cleaning Video

Descaling & Sanitizing Instructions – All Pump Models

Drain Pump System

- 1 Clean the bin liner of mineral scale by using any leftover descaling solution to scrub the scale off the liner. If none is left over, mix a solution of 2.5 ounces of Clear One Concentrated Scale Remover and 1 quart of water
- 2 After ice melts, pour 1 qt. of water down the bin drain until the pump turns on. Once pump turns on IMMEDIATELY stop
- 3 Once pump shuts off, add a mixture of 10 oz of water and 4 oz of descaling solution to bin drain. If the pump cycles during this process, then repeat step 2; making sure to stop pouring as soon as the pump turns on. Then repeat step 3
- 4 Let machine sit in off state for 1/2 an hour
- 5 Rinse the liner with hot water
- 6 Create a solution of sanitizer by mixing 1 gallon (4 liters) of clean, warm potable water (105-115°F) with 1.6 oz of locally approved sanitizer and sanitize the bin interior and flush the drain
- 7 Pour 1 qt. of water down the bin drain until the pump turns on. Once pump turns on IMMEDIATELY stop
- 8 Once the pump shuts off, mix 13 oz of clean, warm potable water (105-115°F) with 1 oz of locally approved sanitizer to sanitize the bin interior. If the pump cycles during this process, then repeat step 7; making sure to stop pouring as soon as the pump turns on. Then repeat step 8
- 9 Let machine sit in off state for 10 minutes
- 10 Rinse the liner with hot water
- 11 Push and release the On/Off button to restart ice making



Part #19-0653 Clear One
Concentrated Scale Remover